# **ME542 Economical Microstepping Driver**

### 1. Introduction

The ME542 is an economical microstepping driver based on patented technology of Leadshine. It is suitable for driving 2-phase and 4-phase hybrid stepping motors. By using the advanced bipolar constant-current chopping technique, it can output more speed and torque from the same motor, compared with traditional drivers, such as L/R drivers. Its 3-state current control technology allows coil currents to be well controlled and with relatively small current ripple, therefore less motor heating is achieved.



### 2. Features

- Low cost and good high-speed torque
- Supply voltage up to +50VDC
- Output current up to 4.2A
- Optically isolated input signals
- Pulse frequency up to 300 KHz
- Automatic idle-current reduction
- 3-state current control technology

- 15 selectable resolutions
- Suitable for 2-phase and 4-phas motors
- DIP switch current setting with 8 different values
- CW/CCW mode available (optional)
- Over-voltage and short-circuit protection
- Small size (118x75.5x33mm)

### 3. Applications

Suitable for a wide range of stepping motors from NEMA size 17 to 34. It can be used in various kinds of machines, such as X-Y tables, labeling machines, laser cutters, engraving machines, pick-place devices, and so on. Particularly adapt to the applications desired with low vibration, high speed and high precision.



# 4. Specifications and Operating Environment

### **Electrical Specifications** $(T_i = 25^{\circ}C)$

Parameters	ME542				
Parameters	Min	Typical	Max	Unit	
Output Current	1.0	-	4.2 (3.0A RMS)	A	
Supply voltage	20	36	50	VDC	
Logic signal current	7	10	16	mA	
Pulse input frequency	0	-	300	Khz	
Isolation resistance	500			ΜΩ	

#### **Operating Environment and other Specifications**

Cooling	Natural Cooling or Forced cooling			
	Environment	Avoid dust, oil fog and corrosive gases		
	Ambient Temperature	0℃ - 50℃		
Operating Environment	Humidity	40%RH — 90%RH		
	Operating Temperature	70°C Max		
	Vibration	$5.9 \text{m/s}^2 \text{Max}$		
Storage Temperature	-20°C − 65°C			
Weight	Approx. 280 gram (9.9 oz)			

# **Mechanical Specifications** (unit:mm, 1 inch = 25.4 mm)




Figure 1: Mechanical specifications

\*Recommended to use side mounting for better heat dissipation

Tel: +086 0755-26434369 1 Web Site: www.leadshine.com Tel: +086 0755-26434369 2 Web Site: www.leadshine.com

### 5. Pin Assignment and Description

The ME542 has two connectors, connector P1 for control signals connections, and connector P2 for power and motor connections. The following tables are brief descriptions of the two connectors of the ME542.

#### **Connector P1 Configurations**

Pin Function	Details						
PUL+(+5V)	<u>Pulse signal:</u> In single pulse (pulse/direction) mode, this input represents pulse signal, active at each rising or falling edge (set by inside jumper J1); 4-5V when PUL-HIGH, 0-0.5V when PUL-LOW. In double pulse mode						
PUL-(PUL)	(pulse/pulse), this input represents clockwise (CW) pulse, active at high level or low level (set by inside jumper J1). For reliable response, pulse width should be longer than 1.5μs. Series connect resistors for current-limiting when +12V or +24V used.						
DIR+(+5V)	DIR signal: In single-pulse mode, this signal has low/high voltage levels, representing two directions of motor rotation; in double-pulse mode (set by inside jumper J2), this signal is counter-clock (CCW) pulse, active at high level or low level (set by inside jumper J1). For reliable motion response, DIR signal should be ahead of PUL signal by 5μs at least. 4-5V when DIR-HIGH, 0-0.5V when DIR-LOW.						
DIR-(DIR)							
ENA+(+5V)	Enable signal: This signal is used for enabling/disabling the driver. Hig level (NPN control signal, PNP and Differential control signals are on the						
ENA-(ENA)	contrary, namely Low level for enabling.) for enabling the driver and low level for disabling the driver. Usually left <b>UNCONNECTED</b> ( <b>ENABLED</b> ).						

#### Selecting Active Edge or Active Level and Control Signal Mode

There are two jumpers J1 and J2 inside the ME542 specifically for the purpose of selecting active edge or active level and control signal mode, as shown in figure 2. Default setting is PUL/DIR mode and upward-rising edge active.

J1 O J2 O

(a) J1, J2 open circuit

PUL/DIR mode and active at upward-rising edge

J1 o J2

(c)J1 open circuit, J2 short circuit CW/CCW mode and active at high level (The fixed level) J1 **]** J2

(b) J1 short circuit, J2 open circuit PUL/DIR mode and active at downward-falling edge

J1 **1** J2

(d) J1, J2short circuit CW/CCW mode and active at low level (The fixed level)






(e) Positions of J1 and J2 Figure 2: J1 and J2 jumpers

#### **Connector P2 Configurations**

Pin Function	Details
Gnd	DC power ground
+V	DC power supply, 20~50VDC, Including voltage fluctuation and EMF voltage.
A+, A-	Motor Phase A
B+,B-	Motor Phase B

# 6. Selecting Microstep Resolution and Driver Output Current

This driver uses an 8-bit DIP switch to set microstep resolution, and motor operating current, as shown below:



### **Microstep Resolution Selection**

Microstep resolution is set by SW5, 6, 7, 8 of the DIP switch as shown in the following table:

Microstep	Steps/rev.(for 1.8°motor)	SW5	SW6	SW7	SW8
2	400	OFF	ON	ON	ON
4	800	ON	OFF	ON	ON
8	1600	OFF	OFF	ON	ON
16	3200	ON	ON	OFF	ON
32	6400	OFF	ON	OFF	ON
64	12800	ON	OFF	OFF	ON
128	25600	OFF	OFF	OFF	ON
5	1000	ON	ON	ON	OFF
10	2000	OFF	ON	ON	OFF

Tel: +086 0755-26434369 3 Web Site: www.leadshine.com Tel: +086 0755-26434369 4 Web Site: www.leadshine.com



20	4000	ON	OFF	ON	OFF
25	5000	OFF	OFF	ON	OFF
40	8000	ON	ON	OFF	OFF
50	10000	OFF	ON	OFF	OFF
100	20000	ON	OFF	OFF	OFF
125	25000	OFF	OFF	OFF	OFF

ME542 Economical Microstepping Driver

### **Current Settings**

The first three bits (SW1, 2, 3) of the DIP switch are used to set the dynamic current. Select a setting closest to your motor's required current.

#### **Dynamic Current Setting**

•	O			
Peak current (A)	RMS (A)	SW1	SW2	SW3
1.00	0.71	ON	ON	ON
1.46	1.04	OFF	ON	ON
1.91	1.36	ON	OFF	ON
2.37	1.69	OFF	OFF	ON
2.84	2.03	ON	ON	OFF
3.31	2.36	OFF	ON	OFF
3.76	2.69	ON	OFF	OFF
4.20	3.00	OFF	OFF	OFF

Notes: Due to motor inductance, the actual current in the coil may be smaller than the dynamic current settings, particularly under high speed condition.

#### **Standstill Current Setting**

SW4 is used for this purpose. OFF meaning that the standstill current is set to be half of the dynamic current, and ON meaning that standstill current is set to be the same as dynamic current.

The current automatically reduced to 60% of dynamic current setting one second after the last pulse. Theoretically, this will reduce motor heating to 36% (due to P=I<sup>2</sup>\*R) of the original value. If the application needs a different standstill current, please contact Leadshine.

# 7. Typical Connection

A complete stepping system should include stepping motor, stepping driver, power supply and controller (pulse generator). A typical connection is shown as figure 3.






Figure 3: Typical connection

Tel: +086 0755-26434369 Web Site: www.leadshine.com